

How to charge meter?

- User buy electricity from vending department. User can get 20 bit charge token, such as "6418 - 8786 - 2991 - 6780 - 9510".
- User input 20 bit charge token through meter keyboard.
- Charge successfully. Charge amount 300.00. Meter cancel alarm, LED turn to green.



- Charge failed.

20 bit TOKEN is input wrong :



TOKEN is used:



HEXE12 Single Phase Keypad Prepayment Meter

 **HEXING** www.hxgroup.cn

Headquarter: 1418-5 Moganshan Road, Shangcheng Industrial Zone,
310011, Hangzhou City, China
Tel: +86 571 2802 07 67
Fax: +86 571 2802 92 63
Email: market@hxgroup.co




Scan Here to Discover More

Protect Your Revenue

www.hxgroup.cn



Wiring diagram



LCD Display



Symbol Description

LCD DISPLAY	DESCRIPTION
88888888	6+2 format, display data
●	Menyatakan 20 digit Stroom Prabayar diterima atau ditolak meter
III	low battery
—○—	relay disconnect
kWArhZ	energy unit
▼ (S1..S8)	state and event detection
DATE	date
TIME	time
CREDIT	credit
①②③④	tariff

credit status

Green LED on	sufficient credit
Red LED on	remaining credits low, less than 30KWH
Red LED flashing	remaining credits low, less than 20KWH

Code Number	Description
800	TOTAL ENERGY
801	CREDIT
802	DATE
803	TIME
804	METER NUMBER
805	SGC NUMBER
806	OUTAGE REASON
807	METER STATUS
808	PULSE CONSTANT
809	POWER OFF TIMES
810	OVERDRAFT LIMIT
811	URGENT OVERDRAFT
812	CANCEL ALARM
813	Query consumption of last day
814	Query consumption of current month
815	Charge date of last time
816	Charge time of last time
817	Charge amount of last time
818	Charge token of last time
874	Power threshold value 1 of overload
875	Power threshold value 2 of overload
876	Current threshold of overload
877	electricity price of current tariff
878	Maximum current active demand
879	Enter test mode
881	voltage
888	Return token code
891	current